


ercol

bosco

1366 3 door wardrobe

Thank you for purchasing this bosco wardrobe. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



This product is **HEAVY**, Take care when lifting to avoid personal injury and (or) damage to the product.

Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any pieces are missing please contact the retailer from whom you bought this product. The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.


This product takes approximately **30 MINUTES** to assemble with **2 PEOPLE**.


Necessary Tools



Fittings and parts checklist


A	Base unit x 1
B	LH side panel x 1
C	RH side panel x 1
D	Centre panel x 1
E	Back panels x 3
F	Narrow hanging rail x 1
G	Wide hanging rail x 1
H	Top panel x 1
I	Door panels x 3
J	Shelf x 2

K	Anti-tipping kit x 1	
L	14mm screws x 8	
M	25mm screws x 12	
N	18mm screws x 34	
O	Wedge x 2	
P	Wooden dowel x 9	
Q	Shelf pins x 8	
R	M6*30mm bolts x 8	
S	M6*50mm bolts x 4 Half Moon Washer x 4	 
T	Allen Key x 1	




Step by step instructions


- 1, Check that all the wooden dowels are present in the side panels (B & C) & centre panel (D).
With the help of another person locate the side panels & centre panel into the base unit. Secure using (R)M6*30mm bolts.




2. Locate the top panel(H) as shown below secure on the left and right side panels using 4pcs (S)M6*50mm bolt and half moon washers then using 2pcs (R)M6*30mm bolt secure top panel on the top of centre panel.




3. With the help of another person move the wardrobe close to it's final position. If your floor is uneven the other person may need to tilt the wardrobe slightly so that the doors remain square, then fix 3pcs back panels(E) onto side panels(B&C) and centre panel(D) using the 18mm screws(N) as shown below.





4. Secure 9pcs wooden dowels(P) onto the door frame(l) as shown below.




5. Fix the door frame(I) onto the side panels(B&C) and centre panel(D) using the 25mm screws(M) 12pcs as shown below.



6. Push fit the eight shelf pins(Q) and locate the self (J) using 14mm screws(L) 8pcs as shown, Put the hanging rails(F&G) into their rail supports.




7. We recommend that you fix this wardrobe to the wall, using appropriate fixings for your type of wall, see below.




Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure



Brick or Masonry

Use an appropriate wall plug provided you are sure your wall is sound





Cavity wall

Special toggle wall plugs are needed. Seek expert advice

Move the wardrobe into it's final position against the wall. Align the L bracket to the pre drilled holes on the top of your wardrobe in the middle along the back rail and using the 2 x 15mm screws fix the bracket to the top of your wardrobe. Then make a mark on your wall through the two holes of the bracket. Take the wardrobe away from the wall. Then drill two holes in your wall where your marks are. Move the wardrobe back into place, align the bracket up with the holes in your wall and partially tighten the bracket to the wall using appropriate fixings for your type of wall.


8. If the wardrobe needs levelling, use the wedges as shown below.




If the chest is not level on your floor, use the wedges provided. Snap them off, so they do not protrude out from the cabinets legs. You can also snap them lengthways. See diagram right.

9. Check that the doors are aligned correctly. If necessary adjust the door hinges as shown below.



Vertically




Horizontally



Sideways



10. Finally, using the provided Anti-tipping kit(K) to fully tighten the screws to secure the wardrobe to your wall as shown below.



Care and maintenance

Wood Furniture

Wood displays different grain patterns depending on which way it is cut - for example, the 'medullary ray' which can appear on oak furniture is a mark of good quality timber - these are just characteristics of the natural beauty of the wood. Some furniture is also deliberately aged and rustic.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

How to care for your wood furniture

Furniture with a hard lacquer, wax polish or painted surface should be dusted with a dry cloth. When using the surface for serving food and drinks it is best to use protective mats and coasters. Spillages should be wiped up as soon as possible.

Spray polishes are best avoided as they contain silicones which may spoil the furniture's surface by building up over time. Use of cleaning materials containing abrasive compounds, acidic or caustic reagents and any bleaches containing oxidising reagents should be avoided as prolonged use may damage the lacquer surface. Wipe up spills immediately. If sticky marks occur on the surface they can be removed with a dilute solution of warm soapy water. The offending area should be rubbed lightly and then completely dried immediately afterwards, before replacing any mats etc.

Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires. Be particularly careful with solid wood as the lack of humidity caused by central heating can cause damage such as warping.

Safety Instructions

Never drag furniture when moving it, always lift it. Please take care when handling or moving the furniture as careless handling may cause damage or injury. No liability will be accepted for damage or injury caused by incorrectly installed furniture.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Ercol Furniture Ltd, Summerleys Road, Princes Risborough, Buckinghamshire. HP27 9PX www.ercol.com